

**Lista odbiorników telewizyjnych współpracujących z kartą  
Neotion Pocket DTV FTA**

| <b>LCD</b>          |                           | <b>Plasma</b>  |                  |           |
|---------------------|---------------------------|----------------|------------------|-----------|
| <b>Bang-olufsen</b> | Beocenter 6-26            | <b>Hitachi</b> | W50P HR10000     |           |
|                     | BeoSystem 3               |                | P42T01 E         |           |
|                     | Beovision 3-32            |                | P50T01 E         |           |
|                     | Beovision 6-26            |                | P42TP01 E        |           |
|                     | Beovision 7-32 MK I       |                | P50TP01 E        |           |
|                     | Beovision 7-32 MK II      |                | P50XR01 E        |           |
|                     | Beovision 7-32 MK III     |                | P60XR01 E        |           |
|                     | Beovision 7-40 MK I       |                | <b>Panasonic</b> | TH50PZ7   |
|                     | Beovision 7-40 MK III     |                | <b>Samsung</b>   | PS42C67HD |
|                     | Beovision 9-50 MK I       | PS50C67HD      |                  |           |
|                     | Beovision 9-50 MK II      | PS42C6HD       |                  |           |
|                     | <b>Continental Edison</b> | CE-107-FHD-42A |                  | PS50C6HD  |
| CE-81HD32A          |                           | PS42C77HD      |                  |           |
| <b>Hitachi</b>      | L37X01 E                  | PS50C77HD      |                  |           |
| <b>Humax</b>        | LGB-19DRT                 | PS42C7HD       |                  |           |
|                     | LGB-22DRT                 | PS50C7HD       |                  |           |
|                     | LGB-32DST                 | PS42C96HD      |                  |           |
|                     | LGB-19DTT                 | PS50C96HD      |                  |           |
|                     | LGB-22DTT                 | PS42E71HD      |                  |           |
|                     | LGB-22DYT                 | PS42E7HD       |                  |           |
|                     | LGB-19DZT                 | PS63P76FD      |                  |           |
|                     | LGB-22DZT                 | PS58P96        |                  |           |
|                     | LU32-TD1                  | PS50P96FD      |                  |           |
|                     | LP32-TDR1                 | PS58P96FD      |                  |           |
|                     | LP40-TDR1                 | PS42Q7HD       |                  |           |
|                     | <b>Hoher</b>              | 32750 LCD 364  | PS50Q7HD         |           |
|                     | <b>JVC</b>                | LT32DH8        | PS42Q96HD        |           |
| LT32DP8BG           |                           | PS50Q96HD      |                  |           |
| LT26DX7BGE          |                           | PS42Q97HD      |                  |           |
| <b>KCC</b>          | DXKCC080618R              | PS50Q97HD      |                  |           |
|                     | TL1951-BTP                | PS50Q97HD      |                  |           |
| <b>LG</b>           | 37LG6000                  |                |                  |           |
| <b>Philipps</b>     | 47PFL5522D                |                |                  |           |
|                     | 32PFL7862D/10             |                |                  |           |
|                     | 42PFL7862D/10             |                |                  |           |
|                     | 47PFL9532D/10             |                |                  |           |
|                     | 32PFL9632D/10             |                |                  |           |
|                     | 37PFL9632D/10             |                |                  |           |
|                     | 42PFL9632D/10             |                |                  |           |
|                     | 47PFL9632D/10             |                |                  |           |
|                     | 52PFL9632D/10             |                |                  |           |
|                     | 37PFL9642D/19 (Mp4)       |                |                  |           |
|                     | 37PFL9732D/10             |                |                  |           |
|                     | 42PFL9732D/10             |                |                  |           |

|                 |                     |
|-----------------|---------------------|
| <b>Philipps</b> | 47PFL9732D/10       |
|                 | 42PFL9742D/19 (Mp4) |
|                 | 42PFL9900D/10       |
| <b>Samsung</b>  | LE32A456C2DXXC      |
|                 | LE46A566P1XZF       |
|                 | LE46A676A1MXZF      |
|                 | LE46F86BD           |
|                 | LE52F86BD           |
|                 | LE70F86BD           |
|                 | LE46M86BD           |
|                 | LE46N87BDX          |
|                 | LE40N87BX           |
|                 | LE40N87D            |
|                 | LE26R52BD           |
|                 | LE19R86BD           |
|                 | LE23R86BD           |
|                 | LE32R86BD           |
|                 | LE37R86BD           |
|                 | LE40R86BD           |
|                 | LE26R86BDX          |
|                 | LE19R86WDX          |
|                 | LE32R88BD           |
|                 | LE32S67BD           |
|                 | LE37S67BD           |
|                 | LE40S67BD           |
|                 | LE22S86BD           |
|                 | LE32S86BD           |
|                 | LE40S86BD           |
|                 | <b>SHARP</b>        |
| <b>SONY</b>     | KDL-20B4030         |
|                 | KDL-23B4030         |
|                 | KDL-26B4030         |
|                 | KDL-20B4050         |
|                 | KDL-23B4050         |
|                 | KDL-26B4050         |
|                 | KDL-32D2600         |
|                 | KDL-40D2600         |
|                 | KDL-32D2710         |
|                 | KDL-40D2710         |
|                 | KDL-32D2810         |
|                 | KDL-40D2810         |
|                 | KDL-32D3000         |
|                 | KDL-40D3000         |
|                 | KDL-46D3000         |
|                 | KDL-32D3010         |
|                 | KDL-40D3010         |
|                 | KDL-46D3010         |
|                 | KDL-40D3400         |
|                 | KDL-46D3400         |
| KDL-40D3500     |                     |
| KDL-46D3500     |                     |

|             |              |
|-------------|--------------|
| <b>SONY</b> | KDL-40D3550  |
|             | KDL-46D3550  |
|             | KDL-40D3660  |
|             | KDL-46D3660  |
|             | KDL-XXE4000  |
|             | KDL-40E4020  |
|             | KDL-15G2000E |
|             | KDL-20G3000  |
|             | KDL-19L4000  |
|             | KDL-40L4000  |
|             | KDL-26P3000  |
|             | KDL-32P3000  |
|             | KDL-37P3000  |
|             | KDL-40P3000  |
|             | KDL-26P3010  |
|             | KDL-32P3010  |
|             | KDL-37P3010  |
|             | KDL-40P3010  |
|             | KDL-26P3020  |
|             | KDL-32P3020  |
|             | KDL-37P3020  |
|             | KDL-40P3020  |
|             | KDL-32S2000  |
|             | KDL-26S2800  |
|             | KDL-32S2800  |
|             | KDL-40S2800  |
|             | KDL-26S2810  |
|             | KDL-32S2810  |
|             | KDL-40S2810  |
|             | KDL-26S2820  |
|             | KDL-32S2820  |
|             | KDL-40S2820  |
|             | KDL-20S3000  |
|             | KDL-26S3000  |
|             | KDL-32S3000  |
|             | KDL-40S3000  |
|             | KDL-26S3010  |
|             | KDL-32S3010  |
|             | KDL-40S3010  |
|             | KDL-20S3020  |
|             | KDL-26S3020  |
|             | KDL-32S3020  |
|             | KDL-20S3030  |
| KDL-20S3040 |              |
| KDL-20S3050 |              |
| KDL-20S3060 |              |
| KDL-20S3070 |              |
| KDL-40S4000 |              |
| KDL-40S4010 |              |
| KDL-26T2600 |              |
| KDL-32T2600 |              |

|             |               |
|-------------|---------------|
| <b>SONY</b> | KDL-40T2600   |
|             | KDL-26T2800   |
|             | KDL-32T2800   |
|             | KDL-40T2800   |
|             | KDL-26T3000   |
|             | KDL-32T3000   |
|             | KDL-40T3000   |
|             | KDL-40T3500   |
|             | KDL-46T3500   |
|             | TAV - L1. CEL |
|             | KDL-26U3000   |
|             | KDL-32U3000   |
|             | KDL-37U3000   |
|             | KDL-40U3000   |
|             | KDL-40U4000   |
|             | KDL-32V2000   |
|             | KDL-32V2500   |
|             | KDL-40V2900   |
|             | KDL-40V3000   |
|             | KDL-46V3000   |
|             | KDL-40V4000   |
|             | KDL-46V4000   |
|             | KDL-52V4000   |
|             | KDL-40V4210   |
|             | KDL-46V4210   |
|             | KDL-40V4220   |
|             | KDL-40V4230   |
|             | KDL-40V4240   |
|             | V4500/V4700   |
|             | KDL-46W2000   |
|             | KDL-40W3000   |
|             | W4000         |
|             | KDL-46X2000   |
| X3000       |               |
| X3500       |               |